




Telescope Temperature Sensors (Temp in Celcius)



- TT1 TT2 TT3 TT4 TT5 TT6 TT7 TT8
- TM1 TM2 TM3 TM4 TM5 TM6 TMS1 TMS2
- TD1 TD2 TD3 TD4 TD5 TD6 TD7 TD8
- TF1 TF2 TF3 TF4 TF5 TF6 TF7 TF8
- TE1 TE2